







CORDLESS SHRUB SHEAR CH 10DL

Item No.	Code No.	Description	No. used	Remarks
1	330882	HOUSING	1	
2	324306	SPRING (A)	1	
3	324298	LOCK-OFF BUTTON	1	
4	330056	NUT M4	10	
5	329837	NUT HOLDER	2	
6	330879	PROTECTOR	1	
7	949423	WASHER M4 (10 PCS.)	6	
8	949217	MACHINE SCREW M4X12 (10 PCS.)	6	
9	301653	TAPPING SCREW (W/FLANGE) D4X20 (BLACK)	6	
10		NAME PLATE	1	
11	324307	SPRING (B)	1	
12	324299	TRIGGER	1	
13	320786	SWITCH	1	
14	330058	INTERNAL WIRE	1	
*15	331067	BATTERY BCL 1015 (EUROPE,AUS,NZL)	1	
*15	331065	BATTERY BCL 1015 (USA,CAN)	1	
16	329839	CONTROLLER (C)	1	
17	330880	MOTOR DC 10.8V	1	
18	329835	WASHER D15	2	
19	329832	SHAFT (B)	1	
20	330055	FIRST GEAR	1	
21A	331755	FINAL GEAR SET	1	
23	329830	SHAFT (A)	1	
24	330878	CRANK CAM ASS'Y	1	INCLUD.25,26
25		PIN (B)	1	
26		CRANK CAM (A)	1	
27	331507	CRANK CASE	1	
28	331508	DUST FELT	1	
29	323211	MACHINE SCREW M4X8 (BLACK)	4	
30	330883	BOTTOM COVER	1	
31		LABEL (USA)	1	
32		LABEL (EURO)	1	
33	319931	U-NUT M4	3	

Item No.	Code No.	Description	No. used	Remarks
34	996689	DISTANCE PIECE	3	
35	949217	MACHINE SCREW M4X12 (10 PCS.)	3	
36		BLADE ASS'Y (CH)	1	
				INCLUD,33,34,35
36		BLADE ASS'Y (CH)	1	
				INCLUD,33,34,35 FOR USA,CAN
37	330884	BLADE CASE	1	
*38	330881	BLADE SET (CH)	1	INCLUD.4,24,27-29,32,36,37,601
39	330886	CRANK CAM ASS'Y	1	INCLUD.40,41
40		CRANK CAM (B)	1	
41		PIN (B)	1	
42		BLADE (CG)	1	
42		BLADE (CG)	1	
				FOR USA,CAN
43	323211	MACHINE SCREW M4X8 (BLACK)	4	
44		LABEL (EURO)	1	
45		LABEL (USA)	1	
46	328030	BLADE COVER (170)	1	
47	330057	BLADE BOX	1	
*48	330887	BLADE SET (CG)	1	INCLUD.4,27,28,39,42,45-47
*48	331258	BLADE SET (CG)	1	INCLUD.4,27,28,39,42,44,46,47 FOR USA, CAN
49	328023	ADJUSTER	1	
		STANDARD ACCESSORIES		
501		CHARGER (MODEL UC 10SFL)	1	
502	330885	CASE	1	
		OPTIONAL ACCESSORIES		
601	330057			