




130MM SABER SAW CR 13VC

Item No.	Code No.	Description	No. used	Remarks
1	321116	BASE (B)	1	
2	321125	FRONT COVER (C)	1	
3	321132	BLADE HOLDER (A)	1	
4A	333738	PLUNGER (B) ASS'Y	1	INCLUD.3,14A,15-19
5A	326232	GEAR COVER (B) ASS'Y	1	INCLUD.6-10
6	318458	FELT WASHER	1	
7	321117	WASHER (H)	1	
8	318459	V-RING	1	
9	321118	O-RING	1	
10	321214	METAL (B)	1	
11	321136	SWING ROLLER	2	
12A	326585	PIN D6	1	
13	321126	COVER CLIP	1	
14A	322708	SPECIAL BOLT M4 SET	1	
15	321130	CAP	1	
16	321131	LEVER (A)	1	
17	321135	SPRING (D)	1	
18	321134	HOLDER PIN (B)	1	
19	318483	SPRING (B)	1	
20	318451	NYLOCK BOLT (W/FLANGE) M6X35	1	
21	318452	WASHER (G)	1	
22A	322142	NYLOCK BOLT (W/FLANGE) M5X12	1	
23	6002DD	BALL BEARING 6002DDCMPS2L	1	
24	314430	SLOTTED HD. SCREW (SEAL LOCK) M4X10	5	
25A	322119	SUB SHAFT (B)	1	
26	967261	RETAINING RING FOR D17 SHAFT	1	
27A	329898	RECIPRO PLATE	1	

Item No.	Code No.	Description	No. used	Remarks
28	6003VV	BALL BEARING 6003VVCMP2L	2	
29	939556	RETAINING RING FOR D35 HOLE (10 PCS.)	1	
30	321128	SECOND SHAFT (B)	1	
31A	318473	GEAR	1	
32	608VVM	BALL BEARING 608VVC2PS2L	1	
33	321124	INNER COVER (B)	1	
34	6001VV	BALL BEARING 6001VVCMP2L	1	
*35A	360616C	ARMATURE 110V- 115V	1	
*35A	360616U	ARMATURE ASS'Y 120V	1	INCLUD.34,39
*35A	360616E	ARMATURE 220V- 230V	1	
*35A	360616F	ARMATURE 240V	1	
36	321122	FAN GUIDE	1	
37	961501	HEX. HD. TAPPING SCREW D5X60	2	TILL 12.2010
37A	953174	HEX. HD. TAPPING SCREW D5X55	2	SINCE 1.2011
38A	340563H	STATOR ASS'Y 110V-115V	1	INCLUD.61
*38A	340563G	STATOR ASS'Y 120V	1	INCLUD.61
*38A	340563J	STATOR ASS'Y 220V-230V	1	INCLUD.61
*38A	340563K	STATOR ASS'Y 240V	1	INCLUD.61
39	608VVM	BALL BEARING 608VVC2PS2L	1	
40A	322120	HOUSING	1	(GREEN)
41	945161	BRUSH CAP	2	
42	999043	CARBON BRUSH (1 PAIR)	2	
43	958900	BRUSH HOLDER	2	
44		NAME PLATE	1	
45	307224	MACHINE SCREW (W/WASHERS)	4	

Item No.	Code No.	Description	No. used	Remarks
46		M5X60 (BLACK) HITACHI LABEL TAPPING SCREW	1	
47	307028	(W/FLANGE) D4X25 (BLACK)	5	
*48	321140	HANDLE (B)	1	
*48	321141	HANDLE (B)	1	FOR NZL,FIJ,AUS
49	981373	TUBE (D)	2	EXCEPT FOR USA,CAN
50A	322133	SWITCH TRIGGER	1	
*51	318505	SWITCH ASS'Y (1P SCREW TYPE)	1	INCLUD.60
*51	318817	SWITCH ASS'Y (1P SCREW TYPE)	1	INCLUD.60 FOR TPE,GBR (110V)
*51	318504	SWITCH ASS'Y (1P SCREW TYPE)	1	INCLUD.60 FOR USA,CAN
*51	320142	SWITCH ASS'Y(1P SCREW TYPE)W/SAFETY LOCK	1	INCLUD.60 FOR NZL,FIJ,AUS
52	981373	TUBE (D)	2	
53	321139	HANDLE (A)	1	
54	938108	TERMINAL	1	FOR NOISE SUPPRESSOR
55	994273	NOISE SUPPRESSOR	1	FOR NZL,FIJ,AUS,GBR,EUROPE,NOR,SWE,DEN,
*55	994273			FIN
56	984750	TAPPING SCREW (W/FLANGE) D4X16	2	
57	937631	CORD CLIP	1	
*58	953327	CORD ARMOR D8.8	1	
*58	938051	CORD ARMOR D10.1	1	
*59	500245Z	CORD	1	(CORD ARMOR D8.8)
*59	500201Z	CORD	1	(CORD ARMOR D10.1) FOR TPE,THA,PHI,PER,
*59	500201Z			BRN,BAN,BOL,TUN,MOZ
*59	500234Z	CORD	1	(CORD ARMOR D8.8) FOR EUROPE,INA,EGY,TUR
*59	500234Z			NGR,SAU,MAR,VIE
*59	500247Z	CORD	1	(CORD ARMOR D8.8) FOR NOR,SWE,DEN,FIN

Item No.	Code No.	Description	No. used	Remarks
*59	500439Z	CORD	1	(CORD ARMOR D8.8) FOR NZL,FIJ,AUS
*59	500423Z	CORD	1	(CORD ARMOR D8.8) FOR SIN,MAL,SRI
*59	500434Z	CORD	1	(CORD ARMOR D8.8) FOR USA,CAN
*59	500435Z	CORD	1	(CORD ARMOR D8.8) FOR GBR (230V)
*59	500237Z	CORD	1	(CORD ARMOR D8.8) FOR GBR (110V)
*60	321960	SWITCH (1P SCREW TYPE)	1	
*60	321961	SWITCH (1P SCREW TYPE)	1	FOR TPE,GBR (110V)
*60	321959	SWITCH (1P SCREW TYPE)	1	FOR USA,CAN
*60	321962	SWITCH (1P SCREW TYPE) W/SAFETY LOCK	1	FOR NZL,FIJ,AUS
61	930703	BRUSH TERMINAL 2 STANDARD ACCESSORIES	2	
501	944458	HEX. BAR WRENCH 4MM	1	
*502	318613	SABER SAW BLADES NO.103 150L P.14 (5 PCS	1	
*502	318621	SABER SAW BLADES NO.132 203L (5 PCS.)	1	FOR USA,CAN
503	321142	CASE OPTIONAL ACCESSORIES	1	
601	959610	SABER SAW BLADES NO.1 (5 PCS.)	1	
602	958182	SABER SAW BLADES NO.2 (5 PCS.)	1	
603	958183	SABER SAW BLADES NO.3 (5 PCS.)	1	
604	959611	SABER SAW BLADES NO.4 (5 PCS.)	1	
605	958185	SABER SAW BLADES NO.5 (5 PCS.)	1	

Item No.	Code No.	Description	No. used	Remarks
606	958188	SABER SAW BLADES NO.8 (5 PCS.)	1	
607	318611	SABER SAW BLADES NO.101 150L P.10 (5 PCS	1	
608	318612	SABER SAW BLADES NO.102 228L P.10 (5 PCS	1	
609	318614	SABER SAW BLADES NO.104 228L P.14 (5 PCS	1	
610	324818	SABER SAW BLADES NO.109 150L P.18 (5 PCS	1	
611	324819	SABER SAW BLADES NO.110 228L P.18 (5 PCS	1	
612	318617	SABER SAW BLADES NO.107 150L P.24 (5 PCS	1	
613	318618	SABER SAW BLADES NO.108 228L P.24 (5 PCS	1	
614	318619	SABER SAW BLADES NO.121 305L P.6 (5 PCS.	1	
615	318620	SABER SAW BLADES NO.131 305L P.10/14(5PC	1	
616	318621	SABER SAW BLADES NO.132 203L (5 PCS.)	1	