




Az Ön kosara üres

DH38SS



Teljes alkatrészlista a(z) DH38SS modellhez

Az alkatrész cikkszámára kattintva megrendelheti a kívánt alkatrészt. A rendelés új fülön (ablakban) fog megjelenni, így az adott modell

alkatrészlistájához bármikor könnyen visszatérhet, és folytathatja a rendelést.

Szám	Cikkszám	Angol megnevezés	Darab	Megjegyzés	Modellnév	Kód
1	331241	RETAINER	1		DH38SS	PRT
2	331243	DUST COVER	1		DH38SS	PRT
3	991697	ROLL PIN D4X20	2		DH38SS	PRT
4	981942	SEAL LOCK HEX. SOCKET HD. BOLT M6X25	4		DH38SS	PRT
5	331238	FRONT COVER	1		DH38SS	PRT
6	319572	O-RING (S-25)	1		DH38SS	PRT
7	331244	O-RING	1		DH38SS	PRT
8	331242	RETAINER PIN	2		DH38SS	PRT
9	990134	DAMPER (B)	2		DH38SS	PRT
10	331240	PUSHING BUTTON	1		DH38SS	PRT
11	331239	SET SPRING	1		DH38SS	PRT
12	331237	CYLINDER CASE	1		DH38SS	PRT
13	991712	HEX. SOCKET HD. BOLT (W/F LANGE) M6X25	4		DH38SS	PRT
14	956996	O-RING (1AS-60)	1		DH38SS	PRT
15	321843	DAMPER (B)	1		DH38SS	PRT
16	331236	DRIVER HOLDER	1		DH38SS	PRT
17	331222	DRIVER	1		DH38SS	PRT
18	313396	O-RING (C)	1		DH38SS	PRT
19	331223	SECOND HAMMER	1		DH38SS	PRT
20	331224	DAMPER WASHER	1		DH38SS	PRT
21	321835	DAMPER	1		DH38SS	PRT
22	331225	DAMPER HOLDER	1		DH38SS	PRT
23	331227	DAMPER HOLDER (B)	1		DH38SS	PRT
24	321832	DAMPER (C)	1		DH38SS	PRT

25	331228	SLIDE RING	1		DH38SS	PRT
26	331226	CYLINDER	1		DH38SS	PRT
27	331232	CYLINDER KEY	2		DH38SS	PRT
28	331230	SLIDE SLEEVE (B)	1		DH38SS	PRT
29	331229	SLIDE SLEEVE (A)	1		DH38SS	PRT
30	331231	SPRING (A)	1		DH38SS	PRT
31	331233	BEVEL GEAR	1		DH38SS	PRT
32	331234	THRUST WASH ER	1		DH38SS	PRT
33	331235	STRIKER	1		DH38SS	PRT
34	986104	O-RING	2		DH38SS	PRT
35	331221	PISTON PIN	1		DH38SS	PRT
36	326369	PISTON	1		DH38SS	PRT
37	321285	CONNECTING ROD	1		DH38SS	PRT
38	6201DD	BALL BEARING 6201DDCMPS 2L	1		DH38SS	PRT
39	325003	DUST WASHER (B)	1		DH38SS	PRT
*40	360875C	ARMATURE 11 0V	1		DH38SS	PRT
*40	360875E	ARMATURE 22 0V-230V	1		DH38SS	PRT
*40	360875F	ARMATURE 24 0V	1		DH38SS	PRT
41	331252	FAN GUIDE	1		DH38SS	PRT
42	953174	HEX. HD. TAPP ING SCREW D 5X55	2		DH38SS	PRT
*43	340753C	STATOR ASS'Y 110V	1	INCLUD.44	DH38SS	PRT
*43	340753G	STATOR ASS'Y 110V	1	INCLUD.44 FOR VEN	DH38SS	PRT
*43	340753E	STATOR ASS'Y 220V-230V	1	INCLUD.44	DH38SS	PRT
*43	340753H	STATOR ASS'Y 220V-230V	1	INCLUD.44 FOR THA,INA,SI N,HKG	DH38SS	PRT
*43	340753J	STATOR ASS'Y 240V	1	INCLUD.44	DH38SS	PRT

44	930703	BRUSH TERMINAL	2		DH38SS	PRT
45	331251	HOUSING ASS'Y	1	INCLUD.86,87	DH38SS	PRT
46	331210	SLIP CLUTCH ASS'Y	1	INCLUD.47-49, 51-59	DH38SS	PRT
47	331211	BEVEL PINION	1		DH38SS	PRT
48	944109	FEATHER KEY 3X3X8	2		DH38SS	PRT
49	331212	COLLAR	1		DH38SS	PRT
50	313050	OIL SEAL (A)	1		DH38SS	PRT
51	6002DD	BALL BEARING 6002DDCMPS 2L	1		DH38SS	PRT
52	331213	WASHER	1		DH38SS	PRT
53	331214	WASHER (A)	1		DH38SS	PRT
54	321281	GEAR HOLDER	1		DH38SS	PRT
55	331218	SPRING (C)	1	0	DH38SS	PRT
56	331217	NEEDLE	1	0	DH38SS	PRT
57	331215	SECOND GEAR	1		DH38SS	PRT
58	331219	SPACER	1		DH38SS	PRT
59	629VVM	BALL BEARING 629VV	1		DH38SS	PRT
60	331220	BEARING WASHER (C)	1		DH38SS	PRT
61	992803	SEAL LOCK HEX. SOCKET HD. BOLT M6X20	2		DH38SS	PRT
62	986940	SEAL LOCK HEX. SOCKET HD. BOLT M6X45	4		DH38SS	PRT
63		HITACHI LABEL	2		DH38SS	PRT
64	994192	HEX. SOCKET HD. BOLT (W/F LANGE) M5X16	6		DH38SS	PRT
65	331245	CRANK COVER	1		DH38SS	PRT
66	878713	CYLINDER O-RING (B)	1		DH38SS	PRT
67	331207	CRANK CASE	1		DH38SS	PRT
68	331549	SEAL PACKING	1		DH38SS	PRT

69	939540	RETAINING RING FOR D10 SHAFT (10 PCS.)	1		DH38SS	PRT
70	331208	CRANK SHAFT	1		DH38SS	PRT
71	948391	RETAINING RING FOR D40 HOLE	1		DH38SS	PRT
72	6203DD	BALL BEARING 6203DDCMPS 2L	1		DH38SS	PRT
73	996363	O-RING (S-40)	1		DH38SS	PRT
74	321274	OIL SEAL (B)	1		DH38SS	PRT
75	331209	FIRST GEAR	1		DH38SS	PRT
76	939299	NEEDLE BEARING (M661)	1		DH38SS	PRT
77	331253	GEAR COVER	1		DH38SS	PRT
78	307947	WING BOLT M6X12	1		DH38SS	PRT
79	331248	MOUNT	1		DH38SS	PRT
80	949556	NUT M6 (10 PCS.)	1		DH38SS	PRT
81	331247	HANDLE BOLT	1		DH38SS	PRT
82	331246	BAND	1		DH38SS	PRT
83	330209	SIDE HANDLE	1		DH38SS	PRT
84	945161	BRUSH CAP	2		DH38SS	PRT
85	999043	CARBON BRUSH (1 PAIR)	2		DH38SS	PRT
86	958900	BRUSH HOLDER	2		DH38SS	PRT
87	938477	HEX. SOCKET SET SCREW M5 X8	2		DH38SS	PRT
88	982631	WASHER (A)	1		DH38SS	PRT
89	608VVM	BALL BEARING 608VVC2PS2L	1		DH38SS	PRT
90	331254	BEARING HOLDER	1		DH38SS	PRT
91	331202	TAIL COVER	1		DH38SS	PRT
92	302089	TAPPING SCREW (W/FLANGE) D5X20 (BLACK)	4		DH38SS	PRT

93	331203	NOISE SUPPRESSOR	1	EXCEPT FOR VEN,THA,INA,SIN,HKG,KUW	DH38SS	PRT
94	331204	HANDLE	1		DH38SS	PRT
95	330216	INTERNAL WIRE 270L	1	EXCEPT FOR VEN,THA,INA,SIN,HKG,KUW	DH38SS	PRT
96	959141	CONNECTOR 50092 (10 PCS.)	1		DH38SS	PRT
97		NAME PLATE	1		DH38SS	PRT
*98	500390Z	CORD	1	(CORD ARMOR D8.2)	DH38SS	PRT
*98	500239Z	CORD	1	(CORD ARMOR D10.7) FOR VEN,THA	DH38SS	PRT
*98	500424Z	CORD	1	(CORD ARMOR D8.2) FOR SIN, KUW	DH38SS	PRT
*98	500235Z	CORD	1	(CORD ARMOR D8.2) FOR INA	DH38SS	PRT
*98	500457Z	CORD	1	(CORD ARMOR D10.7) FOR CHN	DH38SS	PRT
*98	500440Z	CORD	1	(CORD ARMOR D8.2) FOR HKG	DH38SS	PRT
*98	500477Z	CORD	1	(CORD ARMOR D10.7) FOR TPE	DH38SS	PRT
*98	500475Z	CORD	1	(CORD ARMOR D8.2) FOR KOR	DH38SS	PRT
*99	958049	CORD ARMOR D8.2	1		DH38SS	PRT
*99	940778	CORD ARMOR D10.7	1		DH38SS	PRT
100	981974	INTERNAL WIRE	1	EXCEPT FOR VEN,THA,INA,SIN,HKG,KUW	DH38SS	PRT
101	313093	SWITCH (C) (2 P SCREW TYPE W/O LOCK)	1		DH38SS	PRT
102	938307	PILLAR TERMINAL	1	EXCEPT FOR VEN,THA,INA,SIN,HKG,KUW	DH38SS	PRT
103	959141	CONNECTOR 50092 (10 PCS.)	1		DH38SS	PRT
104	960266	CORD CLIP	1		DH38SS	PRT

105	984750	TAPPING SCREW (W/FLANGE) D4X16	2		DH38SS	PRT
106	331205	HANDLE COVER	1		DH38SS	PRT
107	307028	TAPPING SCREW (W/FLANGE) D4X25 (BLACK)	2		DH38SS	PRT
108	331547	DUST SEAL	1		DH38SS	PRT
501	331206	CASE	1		DH38SS	STA